



**NOTES:**

- FORM NEW CURB & GUTTER SO THAT CONTROL JOINTS LINE UP ACROSS STREET.
- SAW CUTS MUST BE ALIGNED W/ CURB & GUTTER CONTROL JOINTS.
- SAW CUTS MUST BE MADE FOR ALL MH & GV CASTINGS.

**135 - TYPICAL SAWED/SEALED JOINT LAYOUT**  
 135 - Saw-Seal (Layout).dwg 6/2015

H:\Cad\_Comm\Details Updated\0 - STREET\135 - Saw-Seal (Layout)

**CITY OF BLOOMINGTON MINNESOTA**  
 1700 W 98TH ST.  
 BLOOMINGTON MN 55431  
 PHONE (952) 563-8700

**ENGINEERING DIVISION  
 PUBLIC WORKS DEPARTMENT**

**PLATE NAME:**

**135 - Saw-Seal (Layout)**

LAST REVISED: 6/5/2015

LAST REVISED BY: KBO